

Spy On A Bird™

Birdfeeder with Wireless Camera



Birdfeeder with Wireless Camera instructions

What's in the Box

Birdfeeder in your choice of material and color

2.4 GHz Wireless Camera premounted on the Birdfeeder

2 power adaptors (one for camera and one for receiver)

Movable perch/cleaner

Birdseed

A/V cables



Receiver for camera



Setting up your Birdfeeder

1. Mount feeder in a desirable location. Remember to keep the feeder less than 100 feet from the receiver or the signal may be diminished.
2. Plug power adaptor into camera. This power adaptor is rated for indoor use. Please protect from the elements. A weatherproof 100 ft AC power cord is available separately.
3. Plug A/V cable from the receiver to the A/V input of the TV or VCR. Select the proper input channel of your TV or VCR. (Refer to manual)
4. Plug power adaptor into receiver

Helpful Hints

Always test the Birdfeeder indoors before mounting outside.

Camera may have shifted during shipping. To re-adjust the camera position, manually tilt the camera until the picture is centered. The camera is pre-focused approximately to the end of the platform.

The camera channel is marked on the lower left of the left side of the Birdfeeder and on the back of the camera. The receiver channel is preset to the camera.

Technical considerations:

The camera is weather resistant, but if direct rain soaking occurs, some condensation will collect on the inside glass. Also, if the camera has not been used for some time, you may notice “fogging” of the lens. This usually clears after a few minutes of use.

The microphone is very sensitive. You may have to turn the volume down on your TV to hear properly.

Sometimes, small adjustments in the location of the camera or the receiver can improve the reception.

Certain electronics may interfere with the camera reception; such as cordless telephones and wireless internet routers.

Microwave ovens may interfere with the signal while in use.

Your neighbors' microwave oven, cordless telephone and wireless router may also interfere with your camera reception.

Temporary interference will occur if the wireless signal is obstructed, such as by moving the receiver or walking through the signal path.

Optional Accessories

12 ft power extension cable



25 ft A/V cable



Video Adaptor



Long range antenna



100 ft AC power adapter



For more information on these accessories and other products, please visit our website. www.SpyOnABird.com

Warranty

Every unit is tested and is guaranteed to work right from the box. Within the first 7 days, if you are not satisfied for any reason, please call us at 1-800-606-6428 and we will assist you in returning the items and issue a refund for the purchase price. Customer pays return shipping.

Every item also comes with a 6-month warranty from the purchase date. Please retain your original invoice. Damage related to normal wear and tear is excluded from this guarantee. Sorry – squirrel damage is not covered under our policy.

Disclaimer

Please obey all local laws and ordinance when operating these products. These products are prohibited from illegal activities. Our company shall not be responsible for any consequences of illegal conduct by the user